

- Strip cable to recommended dimensions.
- Slip heat shrink and crimp ring onto stripped cable.
- Insert the stripped cable through the retaining nut, shield sleeve. 3. and spacer.
- Solder the socket to the center conductor.
- Insert the socket into the pin insulator, then screw the main body onto the retaining nut.
- Wrap the braid around the tail of the body and crimp the ring with a 0.213" hex crimp tool (or one labeled for use with RG-58 cable).
- Use heat shrink to cover crimp.
- Use the nut and washer to secure the connector to a case.

- AND EDGES .02 MAXIMUM.
- SOURCED MATERIALS.

WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS.

MATERIAL: TOLERANCES: PROJECTION: .020 [0.50]-.200 [5.00]= ±.008 [0.20] .200 [5.00]-1.200 [30.00]= ±.016 [0.40] 4.75 [120.0]-12.40 [315.0]=±.040 [1.0] ANGLES: ±1° SIZE FINISH: DRAWN: B.MURPHY DT: 29-JUN-12

ENGR: S.HOGAN

TITLE:

159 ORT LANE **MERLIN, OR 97532**

SMA FEMALE BULKHEAD MOUNT CABLE END CRIMP FOR RG58 CABLE

DWG. NO. REV CONSMA005-R58 C DT: 29-JUN-12 | SCALE: 2:1 DO NOT SCALE DRAWING SHEET 1 OF 1